

# MODERN AND CLASSIC RECTANGULAR FLUSH PULL HOLE PREPARATION

●	FOR CLASSIC TRIM DRILL 4X $\varnothing 1/8"$ X $3/4"$ DEEP PILOT HOLES
○	FOR MODERN TRIM DRILL 2X $\varnothing 1/8"$ X $3/4"$ DEEP PILOT HOLES
	GRAYED POCKET AREA $1/4"$ DEEP

